

# Russell Taylors

E-WARRANTY



[www.russelltaylors.co.uk](http://www.russelltaylors.co.uk)

**USER MANUAL**

**MULTICOOKER MC5**



## **Before Use**

1. Plug in the power cord. Place the glass lid securely on the base. When powered on, the digital display will beep, show "888" for 1 second, then display "---" to indicate it has entered the standby mode.
2. Fill the pot with water according to the level markings on the pot. Do not fill above the MAX line or below the MIN line. For rice or porridge, add water according to the corresponding markings.
3. The digital display shows the working time and power level. Power levels are displayed as P1–P6 (P6 = maximum) and the working time counts down in minutes (1 = 1 minute).
4. The control panel includes: On/Off, Functions, Adjustment, and Time Preset buttons.

## **Control Functions**

### **On/Off Button**

- Starts or cancels the selected function.
- After choosing a function (indicator flashing), press On/Off to begin.
- To cancel during operation, press On/Off again.

### **Functions Button**

- Select from: Keep Warm, Steam, Rice, Porridge, Noodles, Soup, Fry, Hot Pot.
- After selection, the indicator flashes. Press On/Off to start.
- If no action is taken, the display flashes for 1 minute, returns to standby ("--"), and powers off ("OFF") after 3 minutes.

### **Adjustment Button**

- Sets heating time and power level.
- Adjusts in cycles from high to low.
- Short press = +5 minutes. Long press = +10 minutes.

## **Time Preset Button**

- Available for Rice, Porridge, Noodles, Soup.
- After selecting a function, press the Time Preset button to set the preset time.
- Short press = +5 minutes. Long press = +10 minutes.
- The display shows the total preset time + cooking time.
- The preset indicator light remains on until cooking is completed.

## **Cooking Modes**

### **Keep Warm**

Default: 360 minutes. Adjustable time. After cooking, it displays "OFF". Note: Use preheated food or reheat with another function before keeping warm.

### **Steam**

Default: 60 minutes & adjustable. After cooking, the screen displays "OFF".

Note: Water level must be within MIN-MAX lines.

### **Rice**

Default: 30 minutes & adjustable, with optional time preset if required. After cooking, it keeps warm for 2 hours and then displays "OFF". Note: Follow rice water markings ("1" = 1 cup of rice).

### **Porridge**

Default: 60 minutes & adjustable, with optional time preset if required. After cooking, it keeps warm for 2 hours and then displays "OFF". Note: Follow porridge water markings ("1" = 1 cup; "1/2" = half cup).

### **Noodles**

Default: 20 minutes & adjustable, with optional time preset if required. After cooking, it keeps warm for 2 hours and then displays "OFF". Note: Keep water between MIN-MAX.

## **Soup**

Default: 90 minutes & adjustable, with optional time preset if required. After cooking, it keeps warm for 2 hours and then displays "OFF". Note: Keep water between MIN–MAX.

## **Frying**

Default: 60 minutes. Display alternates between time and power (P1–P6). Adjust power level anytime while cooking. After cooking, the screen displays "OFF".

## **Hot Pot**

Default: 90 minutes. Display alternates between time and power (P1–P6). Adjust power as needed. After cooking, the screen displays "OFF".

Note: Keep water within MIN–MAX. Reduce heat after boiling to avoid overflow.

## **Safety Precautions**

- Do not immerse the appliance in water or other liquids.
- Use only the original power cord provided.
- Do not place on unstable, wet, or heat-sensitive surfaces.
- Keep away from high heat, flammable gas, or explosive environments.
- Never operate unattended.
- Always ensure sufficient water is inside before use.
- Do not place sealed containers inside – explosion risk.
- Keep out of reach of children.
- Allow appliance to cool before cleaning or storing.
- Clean with a soft cloth and mild detergent; never use abrasive materials.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of this appliance by a person responsible to their safety.

## **Cleaning & Maintenance**

- Disconnect power and allow the cooker to cool.
- Wash removable parts (inner pot, lid, steamer) with warm water.
- Keep base and power cord dry; do not immerse.
- Wipe exterior with a soft cloth to avoid scratches.
- Store in a cool, dry place, away from direct sunlight.

# **Russell Taylors**