

Russell Taylors

E-WARRANTY



SCAN HERE

www.russelltaylors.co.uk

3 In 1 Waffle Maker

USER MANUAL

WM3



This product is covered by a 2-year warranty against manufacturing defects. For all warranty claims, please email support@russelltaylors.com and include a copy of your invoice or order ID number as proof of purchase. You are entitled to one (1) warranty claim during the warranty period.

SAFETY PRECAUTIONS

1. Keep this instruction manual and its packaging.
For warranty claims, please send back the product in its original packaging to avoid damage during delivery.
2. Never use the appliance if it is damaged.
3. If the supply cord is damaged, it must be replaced by the Russell Taylors Service Team.
4. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they are given supervision or instructions concerning the use of the appliance in a safe way and understand the hazards involved.
5. Children should not play with the appliance.
Cleaning and user maintenance shall not be made by children unless they are 8 years and older and under adult supervision.
6. Keep the appliance and its cord out of reach of children under the age of 8.
7. Regarding the instructions for cleaning any surfaces in contact with food, refer to the section "CLEANING AND MAINTENANCE" of the user manual.
8. The surfaces of the waffle maker will get hot during use.

9. Do not touch the hot surface. Use the handle while moving the product. Never operate it with wet hands.
10. Do not place the appliance in or near a gas or electric burner.
11. Do not use the appliance outdoors.
12. Always disconnect the appliance from the main power socket when not in use, before moving or cleaning.
13. Never leave the appliance unattended when in use.
14. Do not use the appliance for any purpose other than its intended use. This appliance is only meant for household use.
15. Do not let the power cord hang over the edge of a counter or table or touch hot surfaces.
16. The use of accessories or attachments not recommended by the manufacturer may cause hazards.
17. Operate the appliance in a well-ventilated area. Keep at least 10 cm of space on all sides of the appliance to allow adequate air circulation.
18. Do not allow the appliance to touch curtains, wall coverings, clothing, dishtowels, or other flammable materials when it is in operation.
19. Do not remove food when the appliance is in use.

BEFORE FIRST USE

1. Remove all packaging material.
2. Clean the exterior of the appliance with a slightly damp cloth.
3. Clean the supplied cooking plates in warm soapy water. Dry them thoroughly before replacing them on the appliance.

WARNING! Do not submerge the appliance in water or any other liquid.

OPERATING INSTRUCTIONS

Before you put food in the appliance for cooking, preheat the appliance to achieve best cooking results.

1. Place the appliance on a stable, level, and heatproof surface.
2. Close the cover, and then connect the appliance to the power outlet.
3. When the red indicator lights up, it is indicating that the heating is turned on. When the red indicator

goes off, it is indicating that the temperature is perfect for cooking, the appliance is ready for use.

4. Open the appliance, and place your prepared food on the bottom plate, and then close the appliance. The red ready indicator will turn on again.
5. Wait for 3~8 min when the red light goes off the food is ready. You can also check the progress of the food while it is cooking.
 - a. Normally, cooking takes 3 or 5 minutes for a sandwich, 6 or 8 minutes for waffles and donuts.
6. Open the appliance and remove the food with a spatula (not included). Never use a sharp object (Fork or Knife) as this will scratch the nonstick coating.
2. 7. Disconnect the appliance from the power outlet after use.

NOTES

- The thickness of food is ≤ 4 cm for grill plates.
- The first heating process should take place without any food, let it heat for about ten minutes. There may be a slight development of smoke or a burning smell. This is normal and harmless.
- Due to the manufacturing process, it is normal that the appliance may emit smoke when turned on for the first time.
- While cooking, the green ready indicator cycles on and off to keep the temperature perfect for cooking.
- Do not use sharp, pointed or metal spatulas to avoid damaging the cooking surfaces.

CLEANING & MAINTENANCE

WARNING! Before cleaning, always disconnect the appliance from the power outlet, and allow it to cool down completely.

WARNING! Do not immerse the appliance in water or any other liquid.

- Clean the exterior of the appliance with a slightly damp cloth.
- Clean the supplied cooking plates in warm soapy water. Dry them thoroughly before replacing them on the appliance
- Never use abrasive or chemical cleaning agents.
- Clean the surfaces in contact with food to avoid cross contamination from different types of food. It is recommended to use warm clean water with a mild detergent to clean surfaces that meet food
- Always follow correct food hygiene practices to avoid possibility of food poisoning /cross contamination.

STORAGE

- Always unplug the appliance before storage.
- Always make sure the appliance is cool and dry before storage.
- The power cord can be wrapped around at the bottom of base for storing.

Russell Taylors

www.russelltaylors.co.uk