

Russell Taylors

E-WARRANTY



SCAN HERE

USER MANUAL

TABLE BLENDER

www.russelltaylors.co.uk




TB6

SAFETY RULES

1. Please read this manual carefully before using this product.
2. Do not allow children to operate this product.
3. Please put it on a dry and stable platform. Do not place this product on a hot air furnace or near a hot stove or touch any hot surfaces.
4. Do not hang the power cord on sharp objects, connect to movable objects, touch any hot surface, or tie knots.
5. Do not immerse the power cord, plug or main unit in water or other liquids to prevent leakage and damage.
6. If any wire, plug or the product itself is found to have problems or is damaged, please do not use it and return the product to a service center for inspection and repair.
7. Please use the provided accessories only, using other accessories may result in fire, electric shock, or injury.
8. Before using the product, make sure that all components are properly installed, and confirm that the voltage is consistent with the specifications of the product. Unplug the power plug from the socket when it is not in use.
9. The whole machine is strictly prohibited from no-load operation and overloaded use condition.

10. When cleaning and disassembling parts, make sure that the product is switched off.
11. After the product is used, it must be cleaned accordingly. Be careful when cleaning and installing to avoid cutting your hand.
12. Please wait until all parts have stopped moving before removing the working jar assembly , or the small cup assembly.
13. When the blender jar is placed on the holder, the machine is equipped with a protection mechanism. The stirring cup cover cannot be removed while the blender is switch on.
14. Do not add hot water in the cup. Be careful of being scalded by the steam.
15. Caution : This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised not to play with the appliance.

COMPONENTS VIEW



NO.	Component	Function
1	Grinder Cup	Load food.
2	Grinder Silica Gel Loop	Prevent water leakage.
3	Grinder Blade	Crush food.
4	Grinder Base	Separated from the cup, easy to clean.
5	Main Body	Power source.
6	Blender Cover Cap	Add ingredients.
7	Blender Cover	Prevent food overflowing.
8	Seal Ring	Prevent water leakage.
9	Blender Jar	Load food.

HOW TO USE THE BLENDER JAR


1. Place the appliance on a flat and dry stable surface.
2. Clean the blender jar to ensure that there is no other debris. Cut the fruit to be processed into 15*15*15 mm (MAXIMUM SIZE) cubes, put it into the blender and add appropriate amount of water (NOTE NO MORE THAN 1500 ml), as shown in P1.
3. Push the cap and cover onto the jar, as shown in P2.
4. Place the blender with the cover down into the main body and turn it clockwise until it locks, as shown in P3 to P4.
5. Set the knob to position '0', and plug the power cord into a power source meeting the requirements of the manual.
6. Before using, firstly rotate the knob switch to position 'P' for 2-3 times to perform pre-mixing, then rotate to the corresponding speed gear for mixing. The continuous working period cannot exceed 1 minute. The speed gear number selection and continuous processing times depend on the mixing effect and the quantity of food. The machine should be shut down for at least 3 minutes after working for 1 minute to cool the appliance down.
7. If you need to add food or water during the mixing process, unscrew the cover cap on the top of blender counterclockwise and add it from the feeding chute in the middle.

8. Remove the blender jar, remove the cover, pour into your cup and drink it.

9. After using, please unplug the power cord, wash the jar and make it dry.

Note: This machine is not equipped with safety protection function.

Please do not open the blender cover during working process to avoid injury.




HOW TO USE GRINDER JAR

1. Place the appliance on a flat and dry stable surface.
2. Take out the grinder jar accessories, open it by turning the cup holder counterclockwise.
3. Put coffee beans or other food to be grinded into the jar (as shown in P5). Please make sure that the amount of food does not exceed the MAX scale on the jar.
4. Rotate the cup holder clockwise to tighten it (as shown in P6).
5. Align the pins of the grinder with food in the slot of the main body, screw it clockwise as shown in P7 to P8.
6. Set the knob to position '0', and plug the power cord into a power source meeting the requirements of the manual. Before using, please rotate the knob switch to position 'P' for 1-2 times to ensure the machine runs smoothly. If there is any abnormality, please unplug the power plug then reinstall correctly according to the above steps.
7. If it runs well, before using rotate the knob switch to position 'P' for 2-3 times to perform pre-grinding, then rotate to position '2'.

Continuous working period cannot exceed 30 seconds, the machine should be shut down for at least 1 minute after working for 30 seconds to cool the appliance. You can choose the number of cycles according to your preference for crushed ingredients. The more cycles, the finer the ingredients. Generally, 2-3 cycles can provide a

full powdered effect.

8. After the grinding process, please switch the knob to position '0' to stop the machine, turn off the power, unscrew the grinder jar from the machine body in a counterclockwise direction, turn the cup upside down, tap the cup wall gently to make the powder fall into the cup. Lastly unscrew the cup holder counterclockwise and pour the dry powder into the prepared container ,the grinding work is now complete.



MAINTENANCE & CLEANING

1. Be sure to unplug the power plug to avoid electric shock before cleaning or wiping the machine (It is forbidden to put it in water for cleaning)
2. Except for the main body, all detachable parts can be cleaned with water, the water should be wiped dry immediately after cleaning.

3. When cleaning the blender jar, you could add the proper amount of warm water and detergent into the cup, switch the knob to position 'p' to stir for a few seconds. Then take out the blender jar and rinse it under the tap. Dry all parts after washing.
4. To be stored in dry and ventilated place.
5. Do not use abrasive cleaning the unit.

TROUBLESHOOTING

Problem	Cause	Solution
Machine does not work	Main unit is not plugged in.	Make sure power plug is plugged in properly.
	Blender jar or grinder jar couldn't be assembled well.	Ensure correct assembly, please refer to correct assembly instruction.
	Blender lid doesn't assemble well.	Ensure correct assembly, please refer to correct assembly instruction.
	Haven't rotated switch to 1 or 2 speed	Plug the unit and rotate the switch to speed 1 or 2.