# Russell Taylors



# **DRY IRON**

# www.russelltaylors.co.uk

DI-10



## **Safety Instructions:**

When using your iron, basic safety precautions should always be followed:

- 1. Make sure the power used corresponds with the one indicated on the rating label.
- 2. Use the iron only for needed use as descried in the instruction manual.
- 3. Close supervision is necessary when any appliance is used near children. Do not leave iron unattended while connected or on an ironing board. Burns can occur from touching hot metal parts, hot water or steam.
- 4. Keep the iron out of reach of children.
- 5. Unplug the iron from the main electrical supply before:
  - 1) Cleaning
  - 2) Immediately after use
- 6. Never operate the iron with damaged power cord or plug, or after it has fallen or been damaged in any way. To avoid the risk of electric shock, do not disassemble the iron, take it to a qualified serviceman for examination and repair.
- 7. Do not let cord touch hot surfaces.
- 8. To protect against a risk of electric hazards, do not immerse the iron in water or any other liquid.
- 9. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- 10. The iron must not be left unattended while it is connected to the main supply.
- 11. The iron must be used and rested on a stable surface.
- 12. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.

- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
- 14. Always disconnect from the main supply and always switch off power point when not in use.
- 15. Never immerse in water.
- 16. This appliance is not to be used by children or persons with reduced physical. Sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

# Cautions of the first use:

- 1. The iron has been greased, and as a result, the iron may slightly smoke when switched on for the first time. After a short while, this will cease.
- 2. Before using for the first time, remove any sticker or protective foil from the sole plate. Clean the sole plate with a soft cloth.
- 3. To keep the sole plate smooth, avoid hard contact with metal objects (such as clothes rack, button and slide fastener)

## **Component Name:**




A---Body B---Up Cover C---Thermostat Dial D---Power Indicator Light

E---Skirt

#### Dry Ironing:

- Before running the iron, classify the clothes as per its washing label. The clothes (such as synthetic fabric, silk etc)with lower ironing temperature shall be ironed first, and then iron the clothes(such as wool, cotton and linen etc)with the higher temperature setting.
- 2. Stand the iron on its end, and turn the thermostat dial to the MIN position.
- 3. Plug in the iron and select the temperature by turning the thermostat dial. Wait until the indicator light goes off showing that the required temperature has been reached.

### Type of Fabric and Thermostat Dial Form:



Caution: If the fabric consists of various kinds of fibers, always select the lowest ironing

temperature of the composition of those fibers.

#### After Ironing:

Unplug from the main socket.

#### **Cleaning and Maintenance:**

Before cleaning, remove the plug from the socket and allow the iron to cool down sufficiently.

- 1. Wipe off the sole plate with a damp cloth and a non-abrasive(liquid)cleaner.
- 2. If the fiber is adhered to the sole plate, use a damp cloth of vinegar to wipe off the sole plate.
- 3. Never use strong acid or alkali to avoid damaging the sole plate.
- 4. Stand the iron on its end and let it cool down sufficiently.